

# GF312B

## Portable Three Phase Energy Meter Calibrator with Printer

*GF312B portable three phase energy meter calibrator with printer is used to calibrate three phase, single phase, active and reactive energy meters. And it also can be used as voltage, current and power meter to measure AC parameters of three phase power line. It can measure wave distortion factor and 2nd to 63th harmonic wave.*



### Features

1. Three phase active or reactive electricity energy meter;
2. Calibrate three phase, single phase, active or reactive meter error;
3. Measure U(voltage) of three phase or single phase;
4. Measure I(current) of three phase or single phase;
5. Measure active power of three phase or single phase;
6. Measure reactive power of three phase or single phase;
7. Measure apparent power of three phase or single phase;
8. Measure power factor of three phase or single phase;
9. Measure phase angle between voltage and current;
10. Measure frequency of power line;
11. Display vector diagram;
12. Display waveform of U and I;
13. Analyze and display content of harmonic of U and I;
14. Store and look measured data;
15. Optional 5A, 20A, 100A, 500A, 1000A, 2000A , 3000A current clamp;
16. Measure CT variable ratio;
17. Print the data of measurement on site.



### Parameters

Electrical parameters	
Accuracy	0.05%, 0.1%, 0.2%
Power supply	220V ± 10% or 110V ± 10%, 50/60Hz ± 2Hz
Test Voltage	
Range	0V-600V

Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93

<b>Electrical parameters - continued</b>	
<b>Test Voltage - continued</b>	
Error	±0.05% (30V-600V) ±0.1% (5V-30V)
Harmonic	2 <sup>nd</sup> -63 <sup>st</sup>
<b>Test Current</b>	
Range (direct connection)	20mA-20A
Error (direct connection)	±0.05% (100mA-20A) ±0.1% (20mA-100mA)
Range (Clamp CT)	10mA-3000A
Error (Clamp CT)	±0.2% (100mA-3000A) ±0.5% (10mA-100mA)
Harmonic	2 <sup>nd</sup> -63 <sup>st</sup>
<b>Power measure error</b>	
Active power (direct connection)	±0.05% (0.1A-20A) ±0.1% (0.02A-0.1A)
Reactive power (direct connection)	±0.1% (0.1A-20A)
<b>Energy measure error</b>	
Active energy (direct connection)	±0.05% (0.1A-20A) ±0.1% (0.02A-0.1A)
Reactive energy (direct connection)	±0.1% (0.1A-20A)
<b>Phase angle</b>	
Range	0° ~ 360°
Resolution	0.01°
Error	±0.05°
<b>Frequency</b>	
Range	45Hz-65Hz
Resolution	0.001Hz
Accuracy	0.005Hz
<b>Power factor</b>	
Range	-1 ~ 0 ~ 1
Resolution	0.0001
Error	0.0005
<b>Pulse output</b>	
Energy constant	180000imp/kWh, 1800imp/kWh, 18imp/kWh
Pulse ratio	1:1
Output level	5V

**Electrical parameters - continued**
**Pulse input**

Input channel	1
Input level	5-24V
Input frequency	Max. 2MHz

**Display**

Resolution	6" TFT (640×480)
------------	------------------

**Function**

Vector diagram	Yes
Waveform	Yes
Energy accumulation	Yes
Communication port	RS232
Communication with PC	Yes

**Mechanical parameters**

Dimensions (W×H×D) (mm)	390×200×160
Host Weight (mm)	3
Weight (including Accessories 3pcs 100A clamp CT) (kg)	12

**Environmental conditions**

Ambient temperature	-10°C to 40°C
Relative humidity	30%-85%

Архангельск (8182)63-90-72  
 Астана (7172)727-132  
 Астрахань (8512)99-46-04  
 Барнаул (3852)73-04-60  
 Белгород (4722)40-23-64  
 Брянск (4832)59-03-52  
 Владивосток (423)249-28-31  
 Волгоград (844)278-03-48  
 Вологда (8172)26-41-59  
 Воронеж (473)204-51-73  
 Екатеринбург (343)384-55-89  
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58  
 Иркутск (395)279-98-46  
 Казань (843)206-01-48  
 Калининград (4012)72-03-81  
 Калуга (4842)92-23-67  
 Кемерово (3842)65-04-62  
 Киров (8332)68-02-04  
 Краснодар (861)203-40-90  
 Красноярск (391)204-63-61  
 Курск (4712)77-13-04  
 Липецк (4742)52-20-81  
 Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13  
 Москва (495)268-04-70  
 Мурманск (8152)59-64-93  
 Набережные Челны (8552)20-53-41  
 Нижний Новгород (831)429-08-12  
 Новокузнецк (3843)20-46-81  
 Новосибирск (383)227-86-73  
 Омск (3812)21-46-40  
 Орел (4862)44-53-42  
 Оренбург (3532)37-68-04  
 Пенза (8412)22-31-16  
 Россия (495)268-04-70

Пермь (342)205-81-47  
 Ростов-на-Дону (863)308-18-15  
 Рязань (4912)46-61-64  
 Самара (846)206-03-16  
 Санкт-Петербург (812)309-46-40  
 Саратов (845)249-38-78  
 Севастополь (8692)22-31-93  
 Симферополь (3652)67-13-56  
 Смоленск (4812)29-41-54  
 Сочи (862)225-72-31  
 Ставрополь (8652)20-65-13  
 Казахстан (772)734-952-31

Сургут (3462)77-98-35  
 Тверь (4822)63-31-35  
 Томск (3822)98-41-53  
 Тула (4872)74-02-29  
 Тюмень (3452)66-21-18  
 Ульяновск (8422)24-23-59  
 Уфа (347)229-48-12  
 Хабаровск (4212)92-98-04  
 Челябинск (351)202-03-61  
 Череповец (8202)49-02-64  
 Ярославль (4852)69-52-93

<https://gfuve.nt-rt.ru/> || [gvf@nt-rt.ru](mailto:gvf@nt-rt.ru)